

SPECIFICATIONS




Fig. 1 Shows cover from front side. End view shows lip at the bottom that sits down inside the fireplace. The top side has clearance holes to allow pins to pass through.

DESCRIPTION: Covers are stainless steel and provide a decorative way to protect the interior your Kalea Bay outdoor fireplace. Installation is simple, quick and provides all weather protection year round.

TOOLS NEEDED:

Phillips screwdriver

ASSEMBLY

Step 1: Carefully remove the cover from the carton and peel off the plastic protective coating.

Step 2: Remove handles from package and install them as shown in Fig. 2 wth screws and washers. **Note: DO NOT OVERTIGHTEN SCREWS.**




Fig. 2 Shows end view installing handles.



Step 3: Remove the two outer screws from the underside of the opening or hood.

Note: If you are installing a larger cover on a OFP-60 or OFP-72 then also remove the center screw. (total of 3 screws) See Fig. 3.

Remove two outer screws on OFP-36 & OFP-48. Larger models, OFP-60 & OFP-72 also require removal of the center screw.




Fig. 3 Removing screws from hood.

Step 4: Install the brackets with the hood screws using a Phillips screwdriver. See Fig. 4.





Fig. 4. Installing spacers and screws into fireplace.

Step 5: Install cover, top first, aligning the holes of the cover over the spacers, then resting the bottom edge inside of the opening of the fireplace (See Fig 5). The cover should be flush with the outer face of the fireplace.





WARNING: cover must be removed before operating the fireplace.




Fig. 5. Installing cover into fireplace.



REPLACEMENT PARTS

OFP- 36COV	OFP- 48COV	OFP- 60COV	OFP- 72COV	Description	Part #	Qty.
х				36" Stainless steel cover only	73226	1
	х			48" Stainless steel cover only	74226	1
		х		60" Stainless steel cover only	75226	1
			х	72" Stainless steel cover only	76226	1
х	х	х	х	Handles & Screws	HANDLE ASSEMBLY	2
х				36" HT Silcone Strip (1/16" x 1/2")	2614T62-36	1
	х			48" HT Silcone Strip (1/16" x 1/2")	2614T62-48	1
		х		60" HT Silcone Strip (1/16" x 1/2")	2614T62-60	1
			х	72" HT Silcone Strip (1/16" x 1/2")	2614T62-72	1

Table 2

MAINTENANCE

<u>CLEANING STAINLESS STEEL</u>: Stainless steel may oxidize in the presence of chlorides and sulfides, particularly in coastal areas and other harsh environments, such as the warm, highly humid atmosphere around pools and hot tubs. To provide stain prevention and removal, wash all stainless steel surfaces every 3-4 weeks or as often as required with fresh water and/or a stainless steel cleaner.

Do not use abrasive cleaners or steel wool on any stainless steel parts. Doing so will scratch the finish. Exterior surfaces should be cleaned with warm soapy water. Use a stainless steel or non-abrasive cleaner. Always wipe in the direction of the grain. If you have any questions call the Technical Support line below.

CAUTION: Stainless steel covers can be hot to the touch when installed on your fire pit due to the sun and outdoor temperatures. Always use caution when handling.

FOR TECHNICAL SERVICE, CALL: (800) 966-8126

Firegear Outdoors 17322 Gothard St Huntington Beach, CA 92647 Web Site: www.firegearoutdoors.com

Manual changes often occur, ensure to check the Firegear Outdoor website for any recent updates and warranty information.